


Load Carrier Spare Parts



Lamp (for BC 60, BC 70 & bikelander classic)
left (without wire)

order no.: 950 000 302 003



Lamp (for BC 60, BC 70 & bikelander classic))
right (without cable)

order no.: 950 000 302 004



Lamp (for bikelander)
left (without wire)

order no.: 950 050 306 001



Lamp (for bikelander)
right (without cable)

order no.: 950 050 306 002



Lamp left + right (for bikelander)
inc. wire

order no.: 950 050 302 001



cover for lamp left (for bikelander)

order no.: 950 050 302 003



cover for lamp right (for bikelander)

order no.: 950 050 302 004

Load Carrier Spare Parts



Light cluster arm left (for BC 60, BC 70 & bikelander classic)

order no.: 950 000 631 001



Light cluster arm right (for BC 60, BC 70 & bikelander classic)

order no.: 950 000 631 002



Light cluster arm left (for bikelander)

order no.: 950 050 631 001



Light cluster arm right (for bikelander)

order no.: 950 050 631 002



Light traverse middle (for BC 60 & BC 70)

order no.: 950 000 631 003



holder for licence plate (for bikelander/classic)

order no.: 950 050 631 003



Bracket for licence plate (for BC 60 & BC 70)
(EU-standard size)

order no.: 950 000 631 004

Load Carrier Spare Parts



**clamp for licence plate (for bikelander/
classic)**
2 pieces

order no.: 950 050 631 004



clamp for wire (for bikelander/classic)
6 pieces

order no.: 950 050 642 001



Bracket / bow (for BC 60 & BC 70)

order no.: 950 000 613 001



Bracket / bow (for bikelander/classic)

order no.: 950 050 613 001



**Receiver for bracket (for BC 60, BC 70 &
bikelander/classic)**
inc. 2 x cog wheel

order no.: 950 000 621 001



**Star grip incl. round head screw (for BC 60,
BC 70 & bikelander/classic)**

order no.: 950 000 637 001



**Claw short incl. key / lock (for BC 60 & BC
70)**
inc. keys

order no.: 950 000 633 001

Load Carrier Spare Parts



Claw long incl. key / lock (for BC 60 & BC 70)
inc. keys

order no.: 950 000 633 002



**Claw short incl. key / lock (for bikelander/
classic)**

order no.: 950 050 633 006



**Claw long incl. key / lock (for bikelander/
classic)**

order no.: 950 050 633 007



Claw for 3rd bicycle incl. key / lock

order no.: 950 001 633 004



**knob for claw (2 pieces) (2 stk) (for BC 70 &
bikelander/classic)**

incl. 3 keys
(for version BC 60: part.-no. 950 000 633 003)

order no.: 950 035 633 003



**Rubber for gripping lever (for BC 60, BC 70
& bikelander/classic)**

order no.: 950 000 503 001



Wing left (for BC70 & bikelander/classic)

(for models Portilo (year of construction: -12/11: order no.
950 000 619 001))
(for models BC 60: order no. 950 010 619 002)

order no.: 950 035 619 002

Load Carrier Spare Parts



Wing right (for BC 70 & bikelander/classic)

(for models Portilo (year of construction: -12/11: order no. 950 000 619 001))
(for models BC 60: order no. 950 010 619 003)

order no.: 950 035 619 003



Locking mechanism for wings (for BC 60, BC 70 & bikelander/classic)

4 pieces

order no.: 950 010 627 001



Gear belt incl. Clothing (ratchet belt) (for BC 70 & bikelander/classic)

(for models Portilo (year of construction: -12/11: order no. 950 000 622 001))
(for models BC 60: order no. 950 010 622 001)

order no.: 950 035 622 001



rim protector (for BC 60, BC 70 & bikelander/classic)

4 pieces

order no.: 950 030 622 001



Key (for BC 60, BC 70 & bikelander/classic)

2 pieces
(xx = key number)

order no.: 950 000 513 3xx



Key (for box & platform)

2 pieces
(xx = key number)

order no.: 950 000 513 1xx